

# TWIN FALLS


# AIRPORT LAYOUT

# JOSLIN FIELD


# TWF

## LOCATION

LAT 42°28.91' LONG 114°29.27'



## LAYOUT



ELEVATION 4154

5-21

# TWIN FALLS

# AIRPORT LAYOUT

# JOSLIN FIELD

# TWF

# TWIN FALLS AIRPORT DATA JOSLIN FIELD TWF

VOR FREQ RAD NM LOCATION 4 MILES SOUTH OF TWIN FALLS  
TWF 115.8 ON FIELD

FUEL 100LL, JET A1+, OX 1, 3

RWY 07-25: HIRL  
RWY 07: REIL. VASI (V4L)--GA 3.0° TCH 50'.  
RWY 25: MALSR, PAPI (P4L) - GA 3.0° TCH 55'.

## AIRPORT REMARKS:

ATTENDED 1330-0300Z. ADDITIONAL FUEL SERVICE FEE BETWEEN 0300-1330Z, CALL 208-733-5920, 326-4034 FOR INFORMATION. RWY 12-20, TWY G, TWY H, TWY J, AND TWY K ARE NON-AIR CARRIER MOVEMENT AREA. WHEN TOWER CLOSED, ACTIVATE HIRL RWY 07-25, MALSR RWY 25 AND REIL RWY 07 WITH CTAF. NO LINE OF SIGHT BETWEEN APPRCH END RWY 25 AND APPRCH END RWY 12.

WEATHER DATA SOURCES: ASOS 135.025 (208) 733-1878

COMMUNICATIONS: CTAF 118.2 UNICOM 122.95

BOISE FSS (BOISE RADIO) 122.25 1-800-WX-BRIEF.

SALT LAKE CNTR APP/DEP CON 118.05

TWIN FALLS APP/DEP 126.7 (1300-0400Z)

TOWER 118.2 (0600-2100LT) GND CON 121.7

AIRSPACE: CLASS D SVC 1300-0400Z, OTHER TIMES CLASS E.

(L) VORTACW: 115.8 TWF CHAN 105  
N42°28.79' W114°29.37' AT FLD. 4140/18E.

STRIK NDB(LOM): 389 TW  
N42°28.72' W114°21.26' 256° 5.9 NM TO FLD.

ILS: 108.3 I-TWF RWY 25. LOM STRIK NDB.  
ILS UNMONITORED WHEN TOWER CLOSED.

COMM/NAVAID REMARKS: FREQUENCY 121.5 NOT AVAILABLE AT TOWER.

SERVICES: MAJOR A & P REPAIRS, TIEDOWNS, HANGARS, CHARTER, RENTALS, INSTRUCTION, GROUND TRANSPORTATION, FOOD AND LODGING ADJACENT AREA

MANAGER: 208-733-5215

FBOs: REEDER FLYING SERVICE 208-733-5920

5-21